

P. O. Box 704 Birmingham, AL 35201 Phone (205) 995–9800 info@evap.com

Evaporator Operator Training Outline

The following is a <u>partial</u> outline from a pre-evaporator training manual. This manual was developed for an operator training course. Please keep in mind the following attributes of every training course we offer:

- Training customized to your facility. We cover the specific equipment you maintain and operate.
- Training targeted for operators, engineers, and supervisors.
- Process flow sheets specific to your facility are provided and reviewed.
- Training includes field and classroom sessions.
- Plenty of time for Q&A.
- Course manual provided to every student.

1 INTRODUCTION

- 1.1 HISTORY
- 1.2 **EVAPORATORS**
- 1.3 HOW AN EVAPORATOR WORKS
- 1.4 SHELL AND TUBE EVAPORATORS
- 1.5 BASIC EVAPORATOR OPERATION

2 PRINCIPLES OF EVAPORATION

- 2.1 <u>HEAT TRANSFER</u>
- 2.2 HEAT TRANSFER EQUATION
- 2.3 HEAT TRANSFER IN AN EVAPORATOR



3 EQUIPMENT

|--|

- 3.1.1 HEATING ELEMENT
- 3.1.2 FLOWS INSIDE HEATING ELEMENT
- 3.1.3 VAPOR DOMES
- **3.1.4 ENTRAINMENT SEPARATORS**
- 3.2 WHITE WATER HEATERS
- 3.3 SURFACE CONDENSER
- 3.4 VACUUM SYSTEM
- 3.5 CONDENSATE FLASH TANK

4 EVAPORATOR FLOWS

- 4.1 **LIQUOR SYSTEM**
- 4.2 STEAM/VAPOR
- 4.3 CLEAN CONDENSATE
- 4.4 PROCESS CONDENSATE COMBINED
- 4.5 FOUL PROCESS CONDENSATE
- 4.6 NON-CONDENSIBLE GASES
- 4.7 WHITE WATER HEATING
- 4.8 **COOLING WATER**



P. O. Box 704 Birmingham, AL 35201 Phone (205) 995–9800 info@evap.com

5 TROUBLESHOOTING

5.1 Low Capacity

- 5.1.1 Steam Pressure And Condenser Vacuum Are Normal
- 5.1.2 Decreased Steam Flow (Steam Pressure And Vacuum Normal)
- 5.1.3 Normal Or Above Normal Steam Flow (Steam Pressure & Vacuum Normal)
- 5.1.4 Condenser Vacuum is Below Normal
 - **5.1.4.1 Fouled Condenser**
 - **5.1.4.2** High Condensate Level in Condenser
 - 5.1.4.3 Vacuum Leaks
 - **5.1.4.4 Vacuum Pump Problems**
 - **5.1.4.5 Cooling Water Problems**

5.2 CONTAMINATED CONDENSATE

P. O. Box 704 Birmingham, AL 35201 Phone (205) 995–9800 info@evap.com

5.2.1 Foaming

5.2.1.1 Weak Liquor

5.2.1.2 Air

5.2.2 High Liquor Level

- **5.2.2.1 Liquor Transfer Pump Problems**
- 5.2.2.2 Blockage In The Liquor Pipe
- **5.2.2.3 Poor Liquor Level Control**
- **5.2.2.4 Liquor Recycle**

5.2.3 Broken Outside Perimeter Tubes

5.2.4 Entrainment Separator Problems

- **5.2.4.1** Mechanical Damage to Separators
- **5.2.4.2** Improper Drainage
- **5.2.4.3 Plugged Drains**
- 5.2.4.4 Drain Seal "Blow-Out"
- **5.2.4.5 Overload**

5.3 **INSTABILITY**

- 5.3.1 Unsteady Liquor Flow
- 5.3.2 Periodic Vacuum Leak

5.4 CONCLUSION